
Preface

This guide provides feature, add-on module, and specification information for the following telephones:

- Meridian Digital (Modular) telephones
- M3000 Touchphones
- M2317 telephones
- M2000 telephones
- SL-1 telephones
- MCA, MCU and ATA

Other documentation

For more information, refer to the following documentation:

- *Analog Terminal Adapter Quick Reference Card and Installing an Analog Terminal Adapter*
- *Digital telephone line engineering*
- *Meridian Communications Unit and Meridian Communications Adapter description, installation, administration, operation*
- *Spares planning*
- *Meridian 1 equipment identification*
- *Meridian 1 line cards description*
- *Telephone and attendant console installation*
- *X11 features and services*
- *X11 input/output guide*

- *M2000 digital telephone user guide*
- *Asynchronous Data user guide*
- *M2317 user guide*
- *Meridian Modular Telephone user guide—North America*
- *M2216 user guide*
- *Meridian Programmable Data Adaptor user guide*
- *Meridian Communications Adaptor user guide*
- *M3000 Touchphone user guide*
- *Standard 500/2500 Telephone user guide*
- *Meridian Modular Telephone Display quick reference card*
- *M2216 quick reference card*